

## FRONT UPRIGHT INSTALLATION DETAILS

### IMPORTANT NOTE:

When fitting the Front Upright to the Top & Bottom Ball joints, ALWAYS MAKE SURE that the Safety Washers provided are fitted as shown below.

Torque Settings - Top Ball Joint Nut - 25 lbs-ft (34 Nm)  
- Bottom Ball Joint Nut - 28 lbs-ft (38 Nm)

